

TO CARE FOR YOUR HANDLES:

Clean the handles using a microfibre cloth or with a solution of warm water and a small amount of washing-up liquid applied with a soft sponge. Wipe the surfaces dry using a soft cloth. For cleaning, you can also use a clean, damp microfibre cloth without any cleaning agent.

AVOIDING DAMAGE TO THE SURFACE.

To prevent damage to your handles when cleaning, do not use:

- Cleaning agents containing soda, ammonia, acids or chlorides
- Cleaning agents containing descaling agents
- Abrasive cleaning agents, e.g. powder cleaners and cream cleaners
- Solvent-based cleaning agents
- Stainless steel cleaners
- Dishwasher detergent
- Oven sprays
- Glass cleaning agents
- Hard, abrasive sponges and brushes e.g. pot scourers
- Dirt erasers
- Sharp metal scrapers

